

MAN RV 40/54A– Stocks in Huge Numbers

<u>ITEM NAME</u>	<u>PART NO.</u>
VALVE SEAT INSERT	1212
CLAMP PLATE	1040
O RING SEAL RING	1041
THRUST SPINDLE	1226
THRUST SPRING	1212
STARTING AIR PILOT VALVE	613885
STARTING VALVE INSERT	161-1-1001
FEELER PIN	1102
SPRING PIN	1103
PRESSURE SPRING	1104
ADJUSTING SCREW	1105
DISC	1106
SPRING	1107
SPRING CAP	1108
SPRING CAP	1115
THRUST SPINDLE	1116
LOCATING PIN	1117
NUT	1118
NEEDLE INSERT	1119
NOZZLE NEEDLE	1120
BUSH	1121
VALVE SEAT	1122
NON RETURN VALVE	1123
VALVE SPRING	1124
PLUG	1125
SEAL	1126
SCREWED CONNECTION	1130
PLUG	1133
CAP NUT	1134
NOZZLE	1135