

## SULZER AL 25/30 – Stocks in Huge Numbers

<b><u>ITEM NAME</u></b>	<b><u>PART NO.</u></b>
CYLINDER LINER	H21401
CAP FOR INLET AND EXHAUST VALVE	H27077
JOINT BETWEEN CYLINDER LINER AND CYLINDER COVER	H21420
O-RING FOR CYLINDER LINER	H21422
RUBBER RING FOR COOLING WATER GUIDE	H21423
O-RING FOR SLEEVE	H21434
INLET AND EXHAUST VALVE	H27076
VALVE GUIDE FOR INLET AND EXHAUST VALVE	H27153
O-RING FOR VALVE GUIDE	H27108
ANNULAR VALVE SEAT FOR INLET AND EXHAUST VALVE	H27154
ROCKER COMPLETE	H27030
RUBBER JOINT FOR HOODS	H27096
O-RING FOR STARTING VALVE	H27426
JOINT RING FOR INDICATOR VALVE	H27764
JOINT RING FOR INDICATOR VALVE	H27765
PLUNGER AND BARREL FOR FUEL PUMP	H55030
METAFLEX JOINT FOR EXHAUST PIPING	H81153
JOINT FOR AIR PIPE BEND	H82404
O-RING FOR AIR PIPE BEND	H82409
CRANKSHAFT BEARING HALF	H12020
THRUST BEARING RING FOR CRANKSHAFT BEARING	H12010
GROOVED PISTON RING	H34028
PISTON RING (TAPERED PISTON RING)	H34027
PISTON RING, CHROME PLATED	H34026
RETAINING RING FOR GUDGEON PIN	H34029
LOWER CONNECTING ROD BEARING IN TWO PARTS	H33016
UPPER CONNECTING ROD BEARING (BUSH)	H33021
SLEEVE FOR COOLING WATER TRANSITION FROM CYLINDER COVER	H21415
JOINT FOR FRAME COVER	H16198
INSERT BUSH FOR FUEL INJECTOR	H27152
O-RING FOR FUEL INJECTOR	H27106
FUEL INJECTOR COMPLETE	H27200
O-RING FOR NOZZLE HOLDER	H27224

## SULZER AL 25/30 – Stocks in Huge Numbers

NOZZLE COMPLETE FOR FUEL INJECTOR	H27240
DELIVERY VALVE COMPLETE FOR FUEL PUMP	H55054
O-RING FOR FUEL PUMP HOUSING	H55071
O-RING FOR COVER	H55073
O-RING FOR RELIEF PLUG	H55083
BAFFLE SCREW FOR FUEL PUMP	H55053
STOP FOR FUEL PUMP	H55057
PROTECTION TUBE FOR FUEL PRESSURE PIPE COMPLETE	H87600
FUEL PRESSURE PIPE COMPLETE	H87080
SPUR GEAR WHEEL OIL PUMP	H71093
NUT FOR SPUR GEAR WHEEL	H71094
BEARING BUSH FOR OIL PUMP HOUSING COVER	H71012
LOWER COGWHEEL FOR FUEL TRANSFER PUMP	H74119
UPPER COGWHEEL FOR FUEL TRANSFER PUMP	H74120
SPUR GEAR WHEEL FOR FUEL TRANSFER PUMP	H74121
BEARING BUSH	H74103
RETAINING RING	H74150
RUBBER RING	H74151
RUBBER RING	H74152
RUBBER RING	H74168
SEALING DISC FOR FUEL TRANSFER PUMP	H74166
MAIN BEARING	H12020
SPRING FOR STOP	H55066
O-RING FOR FUEL PUMP	H55103
O-RING FOR PROTECTIVE SLEEVE	H40070
O-RING FOR PROTECTIVE SLEEVE	H40071
JOINT FOR FUEL STUD	H27093
FUEL STUD FOR FUEL INJECTOR	H27211
CLAMPING RING FOR FUEL STUD	H27094
THRUST NIPPLE FOR FUEL STUD	H27095
RUBBER JOINT FOR HOODS	H27096
SULZER STARTING VALVE COMPLETE	H27400
RELIEF VALVE COMPLETE	H27700
SPACER FOR CAP NUT	H27219

## SULZER AL 25/30 – Stocks in Huge Numbers

JOINT FOR FUEL INJECTOR	H27223
CAM ROCKER COMPLETE FOR VALVE DRIVE	H40026
ROLLER FOR FUEL PUMP	H55013
BUSH FOR ROLLER	H55014
ROLLER PIN COMPLETE FOR FUEL PUMP	H55015
CONICAL CLAMPING RING IN TWO PARTS	H27078
CAP FOR INLET AND EXHAUST VALVE	H27077
UPPER SPRING PLATE FOR INLET AND EXHAUST VALVE	H27079
LOWER SPRING PLATE FOR INLET AND EXHAUST VALVE	H27080
OUTER VALVE SPRING	H27091
INNER VALVE SPRING	H27092
CYLINDER COVER	H27151
INLET ROCKER	H27041
OUTLET ROCKER	H27046
NOZZLE HOLDER	H27201
CONNECTING ROD BOLT	H33004
PISTON	H34001
GUDGEON PIN	H34021
CAM ROCKER	H40027
PUSH ROD COMPLETE	H40041